

How To Convert Pierced To Clip On Earrings

Courtesy of *Jeweltailor.com*



1. If your earrings already feature a wire or stud fitting, prise open the loop at its base and remove the earwire, using round nose pliers, so that only the bead remains.



2. Take the clip on finding and you will note a loop at its base. Open by gently pulling aside with your pliers and slip the bead through.



3. Close the loop securely so that the join is smooth.



Your earrings are now ready to wear!